

TwinPak Mixing Instructions

Rod and Clip Twinpak

1. Carefully remove outer poly or foil bag without puncturing the inner Twinpak
2. Separate plastic rod from plastic clip and discard.
3. Run the Twinpak sleeve back and forth from end to end over the edge of a bench approximately 40-50 times or 20-25 back and forth cycles.
4. If you see striations, non uniform colour, or if your resins do not have contrasting colours mix an additional 10-15 cycles.
5. Cut off a corner of the Twinpak sleeve and squeeze out the mixed contents. The Twinpak sleeve with mixed residue in most cases can be discarded as non hazardous waste.

Burstable Twinpak

1. Carefully remove outer poly or foil bag without puncturing the inner Twinpak.
2. Roll up one end of Twinpak sleeve and press down to burst seal between A & B.
3. Run the Twinpak sleeve back and forth from end to end over the edge of a bench approximately 40-50 times or 20-25 back and forth cycles.
4. If you see striations, non uniform colour, or if your resins do not have contrasting colours mix an additional 10-15 cycles.
5. Cut off a corner of the Twinpak sleeve and squeeze out the mixed contents. The Twinpak sleeve with mixed residue in most cases can be discarded as non hazardous waste.

Note: Read MSDS prior to mixing or dispensing and use appropriate personal protective equipment i.e. safety glasses and rubber gloves.